



Heater

Pump  
(1 or 2spd)

Aux  
(On/off only  
(Ozone P1=2spd)

SPVSB  
(Variable speed blower)

Circ

Ozone  
(Pump 1 = 1spd)  
- Or -  
(Circ Pump)

View from  
outside enclosure.

Spa bath in bath  
water & temp sensor  
or spa pool in htr water  
& temp sensor

To be fitted  
by spa  
builder or  
installer.

Switch / touchpad

Water + Temp  
Sensor

Dip Sw

Mains

Cordset/Plug is  
model dependant.

To be fitted  
by spa  
builder or  
installer.

Optional Variable or  
Single Coloured Light

Light

Optional spa pool  
in pool temp sensor

Temp  
Sensor

Optional Variable  
Speed Blower

SPVSB

Notes :  
SPVCL, In Pool Temp Sensor & SPVSB are optional.  
Only one temp sensor to be fitted.  
No clock fitted.

<b>© SPA-QUIP LTD</b> P.O.Box 302-114, N.H.P.C. Auckland, New Zealand. PH 64-9-4158622, Fax 64-9-4158621 www.spa-quip.co.nz		Issue : Two	
		<b>SP400 Wiring Diagram</b>	
Approved :		Drawn : SJB 01/12/05	Checked : LH
Sheet 1 of 1	Not to scale	Size : A4	